

PLS No.	Part Number	Description	Qty	Remarks
1	08.25903	Plenum chamber base	1	
2	08.26227	Choke union assembly, APS	1	
3	08.21079	Choke union assembly	1	
4	095.033.0161	Copper washer	2	
5	022.033.0196	Banjo, vacuum tank take off	1	
6	08.26434	Banjo bolt assembly	1	
7	022.033.0202	Sealing washer, banjo	2	
8	692546	Tube, Polyvon, 1/8in dia.	1	
9	08.26123	Air inlet manifold assembly	4	
10	08.25693	Inlet manifold	4	} Part of item 9
11	08.25695	Trumpet, inlet manifold	8	
-	694358	Loctite 648	as reqd	
12	694035	Capscrew, 1/4in UNC x 1in	16	} Plenum base and manifolds to engine
13	692056	Washer, plain, M6	16	
14	08.26566	Plenum chamber assembly top	1	} Part of item 14
-	08.25907	Plenum chamber top	1	
15	08.26573	Bleed stub, air valve	2	
-	694858	Eng. adhesive 648	as reqd	
16	08.26149	Idle air control valve	2	
17	08.26152	'O' ring	2	
18	08.26153	'O' ring	2	
19	08.26150	Clamp ring	2	
20	08.26151	Screw, VAE attachment	4	
21	08.23114	'O' ring	3	Inlet manifold
22	08.26107	'O' ring, top to manifold	3	
23	08.20006	Injector	3	
24	08.20303	Injector retaining clip	3	
25	08.25909	Bolt, plenum chamber top	3	
26	692092	Capscrew M6 x 35	2	Plenum chamber top
27	06.26127	Dowel	2	Plenum chamber top location
28	08.25910	Bolt, plenum chamber top	2	
29	08.26775	Throttle body, RH	1	
30	08.26776	Throttle body, LH	1	
31	08.54412	Tamperproof cap	2	Idle bypass
32	693236	Bolt, M6 x 25	4	} Throttle body to plenum
33	692745	Capscrew, M6 x 25	4	
34	692046	Washer, spring, M6	3	
35	692056	Washer, plain, M6	3	
36	08.26698	Bracket, cable clip	2	} Bracket to plenum
37	692090	Screw, M5 x 12	4	
38	692055	Washer, plain, M5	4	
39	694900	Cable clip	2	
-	694904	Clip, cable to cable	1	RHD
-	692141	Nutlock 242	as reqd	
40	694210	Capscrew, M8 x 16, socket head	2	
41	08.20003	Sensor, air temperature	2	